



# Einstellung Reinigerdosierung GR DDE

Dosierpumpe Grundfos GR DDE			
Einstellung	ml/ h	ml/ min	% Dosierung Reiniger
10	840	14	0,58
20	1704	28	1,18
30	2520	42	1,75
40	3144	52	2,17
50	4032	67	2,79
60	4752	79	3,29
70	5512	92	3,83
80	6216	104	4,33
90	7158	119	4,97
100	7824	130	5,42

